



**These are for guide only you may need more depending on quantity.**

#### **Materials**

- 2 candle wick stickers
- 2 10-ounce glass candle jars
- 1.13 pounds soy wax blend
- 2 pre-waxed cotton wicks
- 2 ounces natural wax scent oil

#### **Tools**

- 1 digital kitchen scale
- 1 candle thermometer
- 2 candle wick holders
- 1 candle melting pitcher



#### **Instructions**

**Use a kitchen scale to measure 1.13 pounds of pure coconut soy wax blend to make 2 candles. Or use a quick candle wax calculator to find the right amount for your containers.**

**To safely melt the wax, pour measured soy wax into a candle melting pot. Place the pitcher filled with wax inside a large saucepan filled with about 2 inches of water. Using the double boiler method, heat on medium to low heat with a gentle simmer at most. Stir often with a metal whisk or heat-resistant silicone spatula.**

**Remove the pitcher from the heat immediately after melting to avoid the wax from becoming too hot or burning. Then use a contact-free infrared thermometer to monitor the temperature of the wax.**

**Allow the temperature of the wax to cool to between 150°F before adding 2 ounces of scent. Thoroughly incorporate the scent by stirring constantly for 2 minutes.**

**If you're working with clear glass candle jars like these, use a heat gun to warm the jars first. Then place a candle wick sticker on the base wick clip and into the centre base of the candle jar.**

**After, gently pour your scented wax into each container. Place an optional centering device over each wick to help keep them in place during the curing process.**