



Vintage Style Cast-Iron Bathroom Privacy Indicator Lock Mounting Instructions



1. Place Inside Section Template so **Door Edge Line** aligns with your door edge. Use **Door Edge Line** on left edge of Inside Section Template for left-handed installation.

2 Drill the two small holes for a #6 screw size.

Outside Section



3. Drill the one large hole 7/16" diameter through door.

4. Mount the inside section with two of the supplied #6 screws.

5. Insert Indicator turn-bar into inside section via hole through door.

6. Place Outside Section onto indicator disc, mark the three screw-holes and mount.

7. Extend Inside Section lever and use door catch to measure two screw holes.

8. Mount door catch.

9. Enjoy your Vintage Style Cast-Iron Bathroom Privacy Indicator Lock.

Door Edge

Door Edge

Inside Section

