

**ADA Compliant Facility Bathroom Privacy
Indicator Door Lock
Drill Template Instructions**



(417) 686-0811

**1. Place the inside section on inside of door
no further than 1/8" from door edge.**

**2. Mark the drill holes and use a 1/8" drill
for all holes. Open up the larger center hole
with a 1/2" drill.**

**Drill 1/2" hole
through door**



3. Mount the inside section with supplied screws.



**4. Use the large center hole to align the outside section and drill the two
small holes with a 1/8" drill. Mount outside section and surface strike.**