



# Partition Door Bathroom Privacy Indicator Lock

Use a 3/16" drill bit for the 4 small holes through door. Use a 5/8" drill bit for the larger center hole through door. Once mounted, extend bolt into occupied position and mount strike on door edge over bolt.

**Left-Hand Door Edge**

**Right-Hand Door Edge**

